



1. After completed endo treatment, open canal with pilot reamer.



2. Calibrate canal with Glassix + reamer.



3. Insert post for fit.



4. Etching.



5. Dry with paper points.



6. Apply layer of bonding.



7. Insert post, cement and light cure.



8. Post is cemented and build up started.



9. Finished work.